





1. There is three kinds of cable components as below:

Power cable		1
I/O cable		1
AV cable		1


3. This I/O Cable is for connecting external other vehicle accessories, like ALRAM ect, if you don't need, just ignore it:

I/O cable		1
-----------	---	---

2 This is the definition of power cable, you need to connect it to your own power:



4. This is how AV Cable to use:



You need to connect cameras to AV IN1/2/3/4, connect monitor to AV OUT one by one.